

WA04024 - Zimma Walker with Wheels

Directions for use

Step 1

Align the middle of your foot with the back legs of the walker.

Step 2

Lift the walker up and place it comfortably in front of you, making sure all four legs end up on the floor.

Step 3

Carefully, walk forward one step at a time.

Wheelchair to Walker

Folding frame



Making certain the wheels on the wheelchair are locked lift your body by pushing down on the armrest and carefully transfer one hand at a time to the walker.

Custom Adjustments

With your arm extended down, the handle should be at wrist height. With your hand placed on the hand-grip, your elbow should be flexed 20° - 30°.

Caution:

Be aware of the following:

- Electrical cords in the way
- Liquids on the floor
- Throw rugs
- Toys or debris
- Furniture
- Doors and door steps
- Gaps in floor

Warning:

- 1. Use wheels on front legs only or on all four legs with appropriate rear wheel brakes.
- 2. Do not push one side of the walker ahead and then other side without lifting the walker first.
- 3. Do not use on stairs or escalators.